

ABI PRISM® dRhodamine 310 CHEMISTRY

10 April 1997

Please select and drag the following files to their appropriate folders.

Please copy the following mobility files into the ABI Folder in the System folder:

DT DSP{dR Set-AnyPrimer}
DT POP6{dR Set-AnyPrimer}

Please copy this file into the Modules folder in the ABI PRISM^a 310 folder:

Seq Run (250 uL) E
Seq POP6 (1 mL) E
Seq POP6 Rapid (1 mL) E